



Nº	Toshiba PN	Description
1	P000220310	PCB FM4SY3
2	P000210080	PCB FM3PS3
3	P000210090	PCB FM3SD3
4	P000204570	PCB FM3LE1
10	P000197540	KEYBOARD UNIT
11	P000218890	HDD UNIT(1.35GB)
12	PA2489UR	MAIN BATTERY (4000mAh)
13	P000220320	COLOR LCD MODULE
13A	P000220330	FL TUBE SET
14	P000220160	FL INVERTER
15	P000204630	NI-MH BATTERY
16	P000204640	NI-MH BATTERY
17	P000204650	MEMBRANE SWITCH
18	P000203500	FDD CABLE
19	PA2438U	AC ADAPTER
20	P000182200	AC CORD SET
30	P000204610	BASE ASSEMBLY
N/S	P000251740	INSULATOR
30A	P000204870	CONNECTOR COVER ASSEMBLY
30B	P000204880	PC CARD COVER
30C	P000204890	FDD CONNECTOR COVER
30D	P000204900	BATTERY LEVER
30E	P000204910	BATTERY KNOB
30F	P000204920	LED LENS
30G	P000196900	SWITCH BUTTON
30H	P000193180	TILT ANGLE, LEFT
30I	P000193190	TILT ANGLE, RIGHT
30J	P000193300	BATTERY STOPPER
30K	P000204930	MEMORY CARD COVER ASSEMBLY
30L	P000193340	KEY PLATE
30N	P000193310	STOPPER SPRING
30O	P000193320	SAFETY CONTACT SPRING
30P	P000204950	SPRING, BATTERY LOCK
30Q	P000193240	BLIND SEAL
30R	P000193350	SPRING PIN
30S	P000193260	WAVE WASHER
30T	P000193230	TILT SCREW
31	P000204860	BASE SUB ASSEMBLY
31A	P000202280	EARTH SPRING
31B	P000198350	BOTTOM CUSHION
31C	P000205680	BRG EARTH SPRING
31D	P000204940	EJECTOR EARTH SPRING
40	P000220340	COVER ASSEMBLY
40-1	P000223730	COVER ASSEMBLY
40A	P000205010	HINGE COVER, LEFT
40B	P000205020	HINGE COVER, RIGHT
40C	P000220360	BRAKE HINGE, LEFT
40D	P000220370	SENSOR HARNESS
40E	P000205050	HINGE BRACKET
40F	P000205060	INSULATOR CORE HOLDER
40G	P000220380	LCD HARNESS
41	P000204960	COVER SUB ASSEMBLY
41B	P000193380	LED LABEL
41C	P000194670	DISPERSIVE FILM
42	P000220350	LCD COVER ASSEMBLY
42-1	P000223560	LCD COVER ASSEMBLY
42A	P000204990	LATCH HOOK
42B	P000205000	LATCH KNOB
42C	P000180400	SPRING B
50	P000220390	LCD MASK ASSEMBLY
50A	P000204670	LCD CUSHION
51	P000204680	SPEAKER HOLDER ASSEMBLY
52	P000204690	KEYBOARD MASK
53	P000204700	BATTERY CONNECTOR COVER
54	P000222340	CABLE GUIDE
55	P000204720	HDD BRACKET ASSEMBLY
56	P000204730	SPEAKER CUSHION
57	P000220400	PC NAME SEAL (C)
57-1	NP620T2	PC NAME SEAL (C)
58	P000220410	PC NAME SEAL (M)
58-1	NP620CT	PC NAME SEAL (M)
59	P000193590	LCD MASK SEAL
60	P000204760	SOUND SHIELD ASSEMBLY
61	P000222180	BLIND FAN SEAL
62	P000204780	MIC HOLDER
63	P000204790	CARE LABEL
64	P000204800	RTC BATTERY HOLDER
65	P000222170	TRANSFER CONNECTOR

66	P000204810	PC SLOT COVER
68	P000204830	SPEAKER
69	P000204840	MICROPHONE
70	P000193060	STICK CAP SET
72	P000205690	SYSTEM SHIELD ASSEMBLY
90	P000220790	FDD 3.5 Inch
90A	P000221810 P000221820	FDD COVER, UPPER
90B	P000221820	FDD COVER, LOWER
90C	P000221830	FDD CONNECTOR
90D	P000221840	FDD SHIELD
90E	P000221850	FDD INSULATOR
<b>OPTIONS</b>		
OP	NW2031U	NW, 8MB MEMORY MODULE
OP	KTT610/8	KINGSTON, 8MB MEMORY
OP	NW2032U	NW, 16MB MEMORY MODULE
OP	KTT610/16	KINGSTON, 16MB MEMORY
OP	NW2034U	NW, 32MB MEMORY MODULE
OP	KTT610/32	KINGSTON, 32MB MEMORY