


Portégé 650CT SYSTEM UNIT (PA1124**X)



N°	Toshiba PN	Description
1	P000225040	PCB FMXSY2
2	P000225050	PCB FMXIO2
1-2	P000225060	PCB FMXIO3
4	P000215910	PCB FLXDA4
10	P000220130	KEYBOARD UNIT
11	P000218890	HDD UNIT(1.3GB)
12	PA2492UR	MAIN BATTERY (3,400mAh)
13	P000220140	COLOR LCD MODULE
13A	P000220150	FL TUBE
13B	P000222400	SCREW M2X2.3
13C	P000222410	SCREW M2X2.3
13D	P000222420	COPPER TAPE
13E	P000222430	ALUMINIUM TAPE
13F	P000222440	FILAMENT TAPE
14	P000220160	FL INVERTER
15	P000220230	NI-MH BATTERY
16	P000220240	NI-MH BATTERY
17	P000220250	MEMBRANE SWITCH
18	P000220260	FDD CABLE
19	PA2438U	AC ADAPTER
20	P000182200	AC CORD SET
21	P000220270	CARD BUS CONNECTOR
22	P000205930	25-10 DC FAN
23	P000220830	SPEAKER
24	P000220280	C-MICROPHONE
25	P000220290	STICK CAP SET
26	P000220300	MODULAR CABLE
30	P000220840	BASE ASSEMBLY
30A	P000220850	SIDE CONNECTOR COVER
30B	P000220860	PRT COVER
30C	P000220870	RS COVER
30D	P000220880	EXPANSION COVER
30E	P000220890	SHAFT EXPANSION COVER
30F	P000220900	EXPANSION COVER SPRING
30G	P000220910	BATTERY LOCK
30H	P000220920	BATTERY LOCK PLATE
30I	P000220930	BATTERY LOCK SPRING
30J	P000220940	SWITCH BUTTON
30K	P000220950	SWITCH STOPPER
30L	P000209490	TILT STAND, RIGHT
30M	P000209500	TILT STAND, LEFT
30N	P000209510	TILT LOCK
30O	P000209530	SPRING TILT STAND
30P	P000209540	SPRING TILT LOCK
30Q	P000209550	SHAFT TILT STAND
30R	P000220960	MEMORY COVER ASSEMBLY
30S	P000220970	ADAPTER EARTH SPRING, LEFT
30T	P000220980	ADAPTER EARTH SPRING, RIGHT
30U	P000220990	KEY HOLDER
30V	P000221000	BASE EARTH SPRING, LEFT
30W	P000221010	BASE EARTH SPRING, RIGHT
30X	P000202280	EARTH SPRING
30Y	P000209600	INSULATOR
30Z	P000221020	SHIELD, LEFT ASSEMBLY
30AA	P000198350	BOTTOM CUSHION
40	P000221080	COVER ASSEMBLY
40-1	P000227850	COVER ASSEMBLY
40A	P000221090	LCD HARNESS
40B	P000221100	COVER
40C	P000221110	LCD COVER
40D	P000221120	HINGE COVER, LEFT
40E	P000221130	HINGE COVER, RIGHT
40F	P000222150	DISPERSIVE FILM
40G	P000221150	LED LENS 4P
40H	P000221160	LED LENS 3P
40I	P000221170	BRACKET HINGE, LEFT
40J	P000221180	BRACKET HINGE, RIGHT
40K	P000221190	HINGE SUPPORT, LEFT
40L	P000221200	HINGE SUPPORT, RIGHT
40M	P000221210	KEYBOARD EARTH, LEFT
40N	P000221220	KEYBOARD EARTH, RIGHT
40O	P000221230	PANEL SWITCH BUTTON
40O-1	P000227080	PANEL SWITCH BUTTON
40P	P000221240	PANEL SWITCH SPRING
N/S	P000227690	PANEL SWITCH SPRING PLATE

40Q	P000221250	LCD LATCH SPRING
40R	P000221260	LCD LATCH
40R-1	P000228170	LCD LATCH
40S	P000221270	INSULATOR SUB BATTERY
40T	P000221280	LED ICON SEAL
40U	P000221290	FIR FILTER
40V	P000221300	KEYBOARD SUPPORT ASSEMBLY, RIGHT
40W	P000221310	KEYBOARD SUPPORT ASSEMBLY, LEFT
40X	P000221320	INSULATOR LCD COVER
40Y	P000222050	LCD COVER CUSHION
40Z	P000222060	HEAT PLATE CUSHION
41	P000221330	LCD MASK ASSEMBLY
41-1	P000229300	LCD MASK ASSEMBLY
41A	P000221340	INSULATOR LCD MASK
41B	P000202500	LCD CUSHION
42	P000193590	LCD MASK SEAL
43	P000221350	HDD GUIDE ASSEMBLY
44	P000221360	BATTERY COVER ASSEMBLY
44A	P000221370	BATTERY SAFETY SPRING
46	P000221380	DAA GUIDE ASSEMBLY
46A	P000221390	DAA PANEL HOLDER
48	P000221400	BATTERY COVER ASSEMBLY
48A	P000221410	BATTERY COVER LATCH
48B	P000221420	BATTERY COVER KNOB
48C	P000221430	BATTERY LATCH SPRING
49	P000221140	CABLE COVER
50	P000222070	REAR PANEL SPRING
52	P000221440	HDD BRACKET ASSEMBLY
53	P000221450	PCMCIA EJECT ASSEMBLY
54	P000221460	SHIELD UPPER ASSEMBLY
55	P000221470	HEAT SINK PLATE, UPPER
56	P000221480	KEYBOARD HOLDER
57	P000221490	IPS SWITCH BUTTON
58	P000221500	DAA COVER
58-1	P000228180	DAA COVER
59	P000221510	PCMCIA COVER
60	P000221520	SPEAKER COVER
61	P000221530	MIC HOLDER
62	P000221540	IPS HOLDER
63	P000221550	SPEAKER BRACKET
64	P000221560	PC NAME SEAL (C)
64-1	NP650T2	PC NAME SEAL (C)
65	P000221570	PC NAME SEAL (M)
65-1	NP650CT	PC NAME SEAL (M)
66	P000221580	HDD COVER ASSEMBLY
67	P000219150	PCMCIA SEAL
68	DOCKING ADAPTER	-
68	P000221590	BASE ASSEMBLY
68A	P000221600	PUSH GUIDE, RIGHT
68B	P000221610	PUSH GUIDE, LEFT
68C	P000221620	HOOK GUIDE, RIGHT
68D	P000221630	HOOK GUIDE, LEFT
68E	P000221640	LEVER CAP
68F	P000221650	LINK AXIS
68G	P000221660	ROLLER
68H	P000221670	SPRING PLATE
68I	P000209590	BOTTOM CUSHION
68J	P000222350	ADAPTER LOCK
68K	P000222360	WASHER
68L	P000193260	WAVE WASHER
68M	P000061110	E-RING 3
N/S	P000236630	PCB SUPPORT, RIGHT
N/S	P000236640	PCB SUPPORT, LEFT
68P	P000221880	HOOK GUIDE ASSEMBLY, RIGHT
68Q	P000221890	HOOK GUIDE ASSEMBLY, LEFT
76	P000222380	SUPPORT BRACKET, RIGHT
77	P000222390	SUPPORT BRACKET, LEFT
78	P000221680	FRONT COVER ASSEMBLY
79	P000221690	COVER
80	P000221700	RAIL
81	P000221710	ADP LABEL
82	P000221720	PCMCIA COVER
90	P000220790	FDD UNIT

90A	P000221810	FDD COVER, UPPER
90B	P000221820	FDD COVER, LEFT
90C	P000221830	FDD CONNECTOR
90D	P000221840	FDD SHIELD
90E	P000221850	FDD INSULATOR
106	P000163450	SCREW M3X4
108	P000211490	SCREW M2.5X6Z
109	P000211510	SCREW M2.5X8Z
110	P000209210	SCREW M3X6Z
112	P000160830	SCREW M2.5X4
113	P000161030	SCREW M2.5X6
114	P000172160	SCREW M2.5X6Z
115	P000160810	SCREW M2.5X8
121	P000161040	SCREW M2X4
121-1	P000229510	SCREW M2X4L
123	P000207950	SCREW M2X4Z
124	P000207940	SCREW M2X6Z
124-1	P000229520	SCREW M2X6L
125	P000209920	SCREW M2.5X4Z
OPTIONS		
OP	NW2038U	NW, 8MB Memory Module
OP	KTT650/8	KINGSTON 8MB Memory Module
OP	NW2039U	NW, 16MB Memory Module
OP	KTT650/16	KINGSTON 16MB Memory Module
OP	NW2043U	NW, 32MB Memory Module
OP	KTT650/32	KINGSTON 32MB Memory Module
OP	NW2044U	NW, 64MB Memory Module
OP	KTT650/64	KINGSTON 64MB Memory Module